

Drywall Finisher



1. The nails should be placed no more than how far on center, when installing drywall on sidewalls
☐ (A) 7" on center ☐ (B) 6" on center
☒ (C) 8" on center ☐ (D) 9" on center
2. Typically used for curved walls.
☐ (A) 11/14" Drywall ☐ (B) 2/5" Drywall
☐ (C) 5/16" Drywall ☒ (D) 1/4" Drywall
3. The activation energy required to overcome during SETTING reaction of Gypsum arises from:
☐ (A) The type of gypsum used in the mixture ☐ (B) The amount of water used in the reaction
☐ (C) Heat generated during the mixing of gypsum ☒ (D) NUCLEATION process - new crystal formation required for the beginning precipitation of dihydrate
4. forms and reinforce arched openings.
☐ (A) Casing Beads ☐ (B) Corner Beads
☒ (C) Arch corner bead ☐ (D) Joint Compound
5. a gypsum basecoat plaster having no admixture except hair or other fiber, used for on-the-job mixing with aggregates
☐ (A) Veneer plaster ☐ (B) Ready-mixed plaster
☒ (C) Neat plaster ☐ (D) Wood-fibered plaster
6. _____ is designed to be used as a base layer in multi-layer systems. Has a gray paper lining on both sides and is not suited for finishing or decorating.
☐ (A) green board ☐ (B) Regular gypsum
☐ (C) Vinyl-surfaced ☒ (D) Backing board

Drywall Finisher

7. contains little or no pigment, produces durable elastic high gloss
- ☐ (A) Latex Paint ☒ (B) Varnish
- ☐ (C) Epoxy Paint ☐ (D) Lacquers
8. _____ is the thickest drywall you can install using a 1-1/2" annular drywall nail.
- ☒ (A) 3/4" ☐ (B) 1-1/4"
- ☐ (C) 1" ☐ (D) 2"
9. Plaster with sound-absorbing fibers or aggregate
- ☒ (A) Acoustic Plaster ☐ (B) Veneer Plaster
- ☐ (C) Skim-coat Plaster ☐ (D) Corner Beads
10. Material used to reinforce drywall joints.
- ☒ (A) Joint Tape ☐ (B) Joint Compound
- ☐ (C) Fiber Mesh Tape ☐ (D) Weather Stripping
11. T-Square
- ☒ (A) Used to make a square cut on the drywall. ☐ (B) Designed for cutting circles in drywall.
- ☐ (C) Meant for measuring angles on drywall. ☐ (D) Utilized for sanding drywall joints.
12. a ready-mixed gypsum plaster applied as a very thin, one or two coat finish over a veneer base
- ☐ (A) Neat Plaster ☐ (B) Gauged Plaster
- ☒ (C) Veneer Plaster ☐ (D) Gypsum Plaster
13. In floating interior angle construction, the ceiling fasteners should be located _____ from the intersection for double nailing
- ☒ (A) 11" to 12" ☐ (B) 14" to 16"
- ☐ (C) 8" to 10" ☐ (D) 6" to 8"

Drywall Finisher

1010. Fasteners shall be spaced not more than ____ inches on center at all supports, and not more than ____ inch from edges.

☐ (A) 4" / 1/2"

☐ (B) 1" / 1/4"

☐ (C) 3" / 5/8"

☒ (D) 2" / 3/8"

1011. expanded-metal, welded-wire, or woven-wire lath that is dimpled to space itself from the supporting surface, creating a space for the keying of plaster or stucco

☐ (A) wallboard

☐ (B) wire lath

☐ (C) paper-backed lath

☒ (D) self-furring lath

1012. When splicing carrier channels there should be a minimum of an ____ inch overlap, with two ____ Gauge wires tied, one on each end.

☐ (A) 6,12

☒ (B) 12,18

☐ (C) 15,24

☐ (D) 10,30

1013. A stucco finish produced by troweling the high spots of a dashed stucco surface before it sets

☒ (A) dash-troweled finish

☐ (B) hard finish

☐ (C) combed finish

☐ (D) float finish

1014. When hand-finishing drywall, the step preceding taping is

☐ (A) Priming the drywall surface

☒ (B) Spotting the fastener heads

☐ (C) Countersinking all fasteners

☐ (D) Applying compound to the joints

1015. Type X Gypsum board

☒ (A) Typically known as fire code board because of its greater resistance to fire

☐ (B) Are the most common type of fasteners for drywall applied to light-gauge metal framing.

☐ (C) The proper professional name for drywall mud.

☐ (D) Are applied to protect exterior corners of drywall from damage or impact

Drywall Finisher

1016. Which of the following statements is false.

- ☐ (A) All drywall joint material is casein based
- ☐ (B) Ridging and cracking are prevented by back blocking
- ☐ (C) the edge of a sheet of drywall that is slightly depressed is called the taped edge
- ☒ (D) In perpendicular installation, the short side of the drywall is attached perpendicular to the studs

1017. When using a loading pump, the best results can be achieved by

- ☒ (A) thinning the compound with water
- ☐ (B) apply compound
- ☐ (C) corner roller
- ☐ (D) using the compound as is

1018. How far apart would nails need scheduled on a ceiling application?

- ☐ (A) 3" OC
- ☐ (B) 1" OC
- ☐ (C) 5" OC
- ☒ (D) 7" OC